


### STEEL DOORS, ALUMINUM ENTRANCES AND WOOD DOORS WITH APPLIED STOPS

FIGURE 2.



DRILL BIT INCLUDED: USE WITH ALL SCREWS (EXCEPT LID SCREWS).

Eliminate bracket, nut and bolt for this installation

### ABOVE ILLUSTRATIONS SHOW TYPES OF INSTALLATION OUT-SWING DOORS

1. Measure from frame side (where door opens) 2 inches in, at header, along applied door stop and mark.
2. Place and center metal disc on magnet cup. Tape side out. (DO NOT REMOVE PAPER LINER)
3. Place chime box edge on applied door stop at 2 inch mark, with magnet cup and metal disc facing door. (See figure. 2)
4. Push chime box forward until metal disc comes in contact with door.
5. Use a pencil and mark around mounting slots. Remove chime box.
6. Drill thru center of each slot mark. By drilling thru center of slot marks, this will allow you to adjust chime box forward or backward after mounting.
7. Mount chime box with 2-#8 X 3/4 truss head sheet metal screws, 2 plain washers and 2 lock washers. (See figure. 2)
8. Open door, peel paper liner off double coated tape on back of metal disc, exposing adhesive. Be sure the area on door where adhesive will stick is clean!
9. Check again that metal disc is centered on magnet cup. Close door, reach inside chime box and push shaft forward, pressing the metal disc against the door. This force will adhere metal disc to door.
10. Drill center of hole in metal disc and secure with 1-#8 X 3/4 truss head sheet metal screw and lock washer. (See figure. 2)
11. Be sure chime box is pushed forward so that magnetic cup is in contact with metal disc. Chime box must be in a straight line with applied door stop. Tighten screws in mounting slots of chime box.
12. Place 2 feet on lid in slots in back of chime box. Push lid in position and secure with 2-#4 X 3/8 lid screws.
13. Your E-Z Tone Chime is now ready to operate.